

Introduction to Image Processing International Days 2022

Romuald Jolivot

Outlines

- General introduction
 - Bangkok University - BU-CROCCS
 - What is image processing?
 - Applications
- Python + OpenCV
 - Requirements
- Basic image processing implementations
- Instagram-like filter implementations
- Conclusions

Before we start

- Presentation, Python codes and test images are available to download on the following link:
 - <https://shorturl.at/lLs1>



General Introduction

Bangkok University - BU-CROCCS

- BU: Private university established in 1962
- BU-CROCCS: Center of Research in Optoelectronics, Communications and Computational Systems established in 2012



BU-CROCCS

- Affiliated with School of Engineering
- Brings together expertise of faculty members with various research background
- Offers internship opportunities (20-30 international interns/year)



Examples of student
projects



Link for internship
applications

BU-CROCCS

Full-time researchers



Dr. Karel Sterckx

- Belgium
- PhD Swansea University (UK)
- Optical Wireless Communication / Software Defined Communication Systems



Dr. Waleed Mohammed

- Egypt
- PhD University of Central Florida (USA)
- Optics / Photonics / Sensors / Nanotechnology / Fiber Optics



Dr. Poompat Saengudomlert

- Thailand
- PhD MIT (USA)
- Digital Communications / Multi-Carrier Modulation / Optical Communications / Optimization



Dr. Romuald Jolivot

- France
- PhD University of Burgundy (France)
- Image Processing

BU-CROCCS

Research projects


- Image processing based:
 - Skin analysis using multispectral acquisition system
 - Innovative Museum Acquisition and Display Systems
 - Digital Make-up system
 - Low-cost phenotypic system for plant growth analysis
- IOT sensor platform
- Optical Wireless Communication (OWC) - Museum and Hospital applications
- Reflection spectrometry

BU-CROCCS

Research projects - image processing

Skin analysis using multispectral acquisition system

- Aim: Collect objective and reproducible quantification of skin optical properties
- System composition:
 - LED light (visible + near infrared)
 - Motor
 - Grating
 - Optical fiber
 - Camera
 - Acquisition time < 5s




BU-CROCCS

Research projects - image processing

Skin analysis using multispectral acquisition system

- Multispectral data processing:
 - Skin component extraction using AI
 - Melanin concentration
 - Hemoglobin concentration
 - Dermis thickness
 - Epidermis thickness
 - etc.



BU-CROCCS

Research projects - image processing

Innovative Museum Acquisition and Display system

- Aims:
 - Automatic digitization of ceramic collections
 - Enhanced display and virtual interaction
- Collaborator:
 - South Asian Ceramics Museum




BU-CROCCS


Research projects - image processing

Innovative Museum Acquisition and Display system


- Acquisition set-up:
 - Based on Raspberry Pi
 - Pi Camera
 - Camera Dolly



Working principle



Schematic set-up



Current set-up

BU-CROCCS


Research projects - image processing

Innovative Museum Acquisition and Display system

- Hologram-like Display Unit:
 - 3 views
 - 4 views



4 views display



3 views display

BU-CROCCS

Research projects - image processing

Innovative Museum Acquisition and Display system

- Hologram-like Display Unit:
 - Cone




Cone display testing setup

BU-CROCCS

Research projects - image processing

Innovative Museum Acquisition and Display system

- Interactive Unit:
 - Kinect interaction - control display by hand
 - Fisheye localisation - detect user position




BU-CROCCS

Research projects - image processing

Digital Make-up system

- Aim: Automatic digital make-up application with 3D-like display





BU-CROCCS

Research projects - image processing

Digital Make-up system

- Automatic make-up area detection




BU-CROCCS

Research projects - image processing

Low-cost phenotyping system for plant growth analysis

- Aim: develop a system for quantitative analysis of plant growth

- System:
 - Raspberry Pi + camera
 - Image processing implementation
- Output:
 - Time-lapse recording
 - Plant growth speed
 - Biological features quantification




BU-CROCCS


Research projects - image processing

Low-cost phenotyping system for plant growth analysis

- Automatic make-up area detection



- AI



Outlines

- General introduction
 - Bangkok University - BU-CROCCS
 - What is image processing?
 - Applications
- **Python + OpenCV**
 - Requirements
 - Setup on PyCharm
- Basic image processing implementations
- Advances implementations
- Conclusions


PyCharm installation

1. Get a student license
2. Download PyCharm Professional IDE
3. Install PyCharm
4. Create New Project (with choice of interpreter)



PyCharm - Create New Project

1. Allows selection of interpreter
2. Select version 3.9 (latest)
3. For demo, keep “Create a main.py” ticked
4. Create a virtual environment




PyCharm - New Project

PyCharm layout:


- Test example “main.py”

1. Folder
2. Name of current file
3. Running button
4. Run display



PyCharm - New Project

Useful windows




```
Python Console ×
/Users/Romu/PycharmProjects/pythonProject1/venv/bin/python /Applications/
import sys; print('Python %s on %s' % (sys.version, sys.platform))
sys.path.extend(['/Users/Romu/PycharmProjects/pythonProject1'])

PyDev console: starting.

Python 3.9.5 (v3.9.5:0a7dcbdb13, May 3 2021, 13:17:02)
[Clang 6.0 (clang-600.0.57)] on darwin


>>>
```

Python Console




Python Packages	
Installed	
setuptools	57.1.0
pip	21.1.3

Python Package installed



```
Terminal: Local × +
(venv) Romus-MacBook-Pro:pythonProject1 Romu$
```

Terminal window




Problems: Current File 35 Project Errors

- Ch5.py ~/PycharmProjects/pythonProject/Lecture code 35 problems
 - PEP 8: E303 too many blank lines (3) :20
 - PEP 8: E402 module level import not at top of file :20
 - PEP 8: E303 too many blank lines (3) :25
 - PEP 8: E402 module level import not at top of file :25
 - PEP 8: E302 expected 2 blank lines, found 1 :27
 - PEP 8: E305 expected 2 blank lines after class or function definition, found 1 :30
 - PEP 8: E402 module level import not at top of file :36
 - PEP 8: E225 missing whitespace around operator :45
 - PEP 8: E713 test for membership should be 'not in' :47
 - PEP 8: E402 module level import not at top of file :55
 - PEP 8: E265 block comment should start with '# ' :76
 - PEP 8: E402 module level import not at top of file :86
 - PEP 8: E302 expected 2 blank lines, found 1 :98

Problems window

PyCharm - Run New Project



The screenshot shows the PyCharm interface with the main.py file open. The code is as follows:

```
# This is a sample Python script.

# Press ⌘R to execute it or replace it with your code.
# Press Double ⇧ to search everywhere for classes, files, tool windows, actions, and settings.


def print_hi(name):
    # Use a breakpoint in the code line below to debug your script.
    print(f'Hi, {name}') # Press ⌘F8 to toggle the breakpoint.

# Press the green button in the gutter to run the script.
if __name__ == '__main__':
    print_hi('PyCharm')

# See PyCharm help at https://www.jetbrains.com/help/pycharm/
```

The Run tool window at the bottom shows the command: /Users/Romu/PycharmProjects/pythonProject1/venv/bin/python /Users/Romu/PycharmProjects/pythonProject1/main.py. The output is: Hi, PyCharm. Process finished with exit code 0.

Run using “Run” short cut



The screenshot shows the PyCharm interface with the main.py file open. The code is identical to the one in the first screenshot.

```
# This is a sample Python script.

# Press ⌘R to execute it or replace it with your code.
# Press Double ⇧ to search everywhere for classes, files, tool windows, actions, and settings.

def print_hi(name):
    # Use a breakpoint in the code line below to debug your script.
    print(f'Hi, {name}') # Press ⌘F8 to toggle the breakpoint.

# Press the green button in the gutter to run the script.
if __name__ == '__main__':
    print_hi('PyCharm')


# See PyCharm help at https://www.jetbrains.com/help/pycharm/
```

The Terminal tool window at the bottom shows the command: (venv) Romus-MacBook-Pro:pythonProject1 Romus\$ python main.py. The output is: Hi, PyCharm. (venv) Romus-MacBook-Pro:pythonProject1 Romus\$


Run using terminal with “python main.py” command

PyCharm - Python Console

- Allow you to run python code directly
- IDE shows variable information
- Browse Queue history






The screenshot shows the PyCharm Python Console window. On the left, there's a sidebar with icons for file operations like copy, paste, and refresh, followed by a list of recent consoles: "PyDev console: starting.", "Python 3.9.5 (v3.9.5:0a7dcdbb13, May 3 2021, 13:17:02)", "[Clang 6.0 (clang-600.0.57)] on darwin", and a session named "test = {int} 4". Below this is a "+" button and a command prompt line starting with ">>>". On the right, there's a "Special Variables" panel showing a single entry: "test = {int} 4". The main console area is currently empty, showing only the command prompt.



The screenshot shows the PyCharm Python Console History window. It displays a list of previously run commands in two columns. The left column contains "test = 2+2", "test = "text\"", and "print("I'n trying so". The right column contains "1 print("I'n trying something")". The window has standard OS X-style controls (red, green, blue buttons) at the top and "Close" and "Paste" buttons at the bottom.

PyCharm - Create new Python file



Python + OpenCV

- Python is widely used
- Computer Vision
 - Everything related to processing image and video
- OpenCV
 - Most complete toolbox for image processing
 - Available on Windows, MacOS, Linux
 - C++, Python, Java and more
 - Python is very popular in the scientific community (similar to Matlab...but free)

Python + OpenCV

- OpenCV
 - Written in C++
 - Free
 - Weak official documentation but improving (now dedicated module for python)
- Loads of example online

Python + OpenCV

Requirements


- Python requires packages
- Development on PyCharm (easy to setup) (pip or Python Packages)
- Image processing needs at least packages: 3

Package name	name on Python package library	version
Numpy	numpy	1.22.1
Matplotlib	matplotlib	3.5.1
OpenCV	opencv-python	4.5.5.62

Python + OpenCV

Requirements - Package installation

- Getting Numpy
- Using Python Packages from PyCharm



Python + OpenCV

Requirements - Package installation

- Check if Numpy is properly installed

try:

import numpy as np

except ImportError as e:

print(f'Install numpy using "pip install numpy" command')

else

print(f'Numpy installed version: {np.__version__}')

- If Numpy is not installed, it prints a message inviting you to install it

pip install numpy


- Else it print the version on the system

Numpy installed version: 1.22.1

Python + OpenCV

Requirements - Package installation

- Getting Matplotlib
 - Using Python Packages from PyCharm



Python + OpenCV

Requirements - Package installation

- Check if Matplotlib is properly installed

try:

import matplotlib as plt

except ImportError as e:

print(f'Install Matplotlib using "pip install matplotlib" command')

else

print(f'Matplotlib installed version: {plt.__version__}')

- If Matplotlib is not installed, it prints a message inviting you to install it

pip install matplotlib


- Else it print the version on the system

Matplotlib installed version: 3.5.1

Python + OpenCV

Requirements - Package installation

- Getting OpenCV
- Using Python Packages from PyCharm



Python + OpenCV

Requirements - Package installation

- Check if OpenCV is properly installed

try:

import cv2

except ImportError as e:

print(f'Install OpenCV using "pip install opencv-python" command')

else

print(f'OpenCV installed version: {cv2.__version__}')

- If Matplotlib is not installed, it prints a message inviting you to install it

pip install opencv-python

- Else it print the version on the system

OpenCV installed version: 4.5.5

Python + OpenCV

Requirements - Package installation

- You can check if all the three packages are installed using
 - “Check_installation.py”

Structure of the lecture

- One - two slides explaining a concept
- One - two slides showing examples (provided in the link too)
- Highly recommend you to implement the examples yourself so you understand how it works.

Advices

- This course brings you image processing basics using Python
- Highly recommend to test the codes and examples in the lectures
- Use other sources to improve your knowledge
- Mastering a language (spoken/programming) takes time
- Be curious
- Don't be frustrated when it doesn't work
- Don't hesitate to ask questions

Outlines

- General introduction
 - Bangkok University - BU-CROCCS
 - What is image processing?
 - Applications
- Python + OpenCV
 - Requirements
- **Basic image processing implementations**
- Instagram-like filter implementations
- Conclusions

Basic image processing implementations



Basic image processing outline

- **Basic**
 - Image reading
 - Image plotting
 - Image properties
 - Image writing
 - Plotting webcam
 - Recording video
 - Playing video
- Histogram
 - What is it?
 - Histogram equalization
 - CLAHE
- Binarization
 - Basic methods
 - Otsu
- Filtering
 - Smoothing filters
 - Average
 - Median
 - Gaussian
 - Sharpening filter
 - Edge Detection
 - Sobel
 - Canny

Basic image processing implementations

Basic OpenCV interaction

- Image formation:



Basic image processing implementations

Reading image

- Reading image using *imread()* function
 - Syntax
 - `loaded_image = cv2.imread('filename.ext', flag)`
 - *imread* loads image in BGR color format (even for grayscale image)
 - *filename.ext*: name of the file (can include path)
 - *flag*: specific reading mode
 - `cv2.IMREAD_COLOR` (default option, not required), can be replaced by “1”
 - `cv2.IMREAD_GRAYSCALE` (8-bit grayscale image), can be replaced by “0”
 - more options (check online)

Basic image processing implementations

Plotting image

- Displaying image using *imshow()* function
 - Syntax
 - `cv2.imshow('title text', variable)`
 - '*title text*' loads text to be displayed on the window
 - *variable*: name of the variable you want to display
 - `cv2.waitKey(time)`
 - *time*: time in millisecond for the windows to stay open, “0” to manually close it
 - `cv2.destroyAllWindows()`
 - *variable*: name of the image variable you want to display

Basic image processing implementations

Reading and plotting image

- Example of displaying “*logo.png*” using “*loading_image.py*”

```
import cv2

# Read image using imread function
image = cv2.imread("logo.png", cv2.IMREAD_COLOR)

# Display image using imshow('title', variable)
cv2.imshow("logo BU-TM", image)

# Need to use waitKey(0) to keep the image displayed on
# waitKey(time_in_millisecond) to keep it on for a specified
# time or 0 for the user to manually close it (pressing keyboard)
cv2.waitKey(0)

# clearing window and memory using (destroyAllWindows)
cv2.destroyAllWindows()
```



logo displayed in a new window

Basic image processing implementations

Reading image in grayscale and plotting it

- Example of displaying “*logo.png*” using “*loading_image.py*”
- Load in grayscale using “0” flag

```
import cv2

# Read image using imread function
image_gray = cv2.imread("logo.png", 0)

# Display image using imshow('title', variable)
cv2.imshow("logo BU-TM", image)

# Need to use waitKey(0) to keep the image displayed on
# waitKey(time_in_millisecond) to keep it on for a specified
# time or 0 for the user to manually close it (pressing keyboard)
cv2.waitKey(0)

# clearing window and memory using (destroyAllWindows)
cv2.destroyAllWindows()
```



Grayscale logo displayed in a new window

Basic image processing implementations

Converting image in grayscale and plotting it

- Converting an image to grayscale using *cv2.cvtColor()* function
 - Syntax
 - `grayim = cv2.cvtColor(colorim, cv2.COLOR_BGR2GRAY)`
 - ‘*colorim*’ color image
 - *cv2.COLOR_BGR2GRAY*: flag conversion from color to grayscale
 - other conversion available (check online)
 - *grayim*: image converted into grayscale

Basic image processing implementations

Converting image in grayscale and plotting it

- Example of displaying “*logo.png*” using “*convert2gray.py*”

```
import cv2
```

```
image = cv2.imread("logo.png", cv2.IMREAD_COLOR)
gray = cv2.cvtColor(image, cv2.COLOR_BGR2GRAY)
cv2.imshow("logo BU-TM", image)
cv2.imshow("Gray converted logo BU-TM", gray)
cv2.waitKey(0)
cv2.destroyAllWindows()
```



logo displayed in a new window



Grayscale logo displayed in a new window

Basic image processing implementations

Extracting image properties

- Extracting properties of image using *shape*, *size*, and *dtype* functions:
- Shape: returns height, width(, channel)
 - Syntax
 - `print(image.shape)`
 - `h, w = image.shape` # for grayscale image
 - `h, w, c = image.shape` # for color image
- Size: returns number of elements in the array ($h \times w (*channel)$)
 - Syntax
 - `image_size = image.size`
- Dtype: Returns the datatype of the array
 - Syntax
 - `image_type = image.dtype`

Basic image processing implementations

Extracting image properties

- Example of properties extraction using “*image_properties.py*“

```
import cv2
```

```
image = cv2.imread('logo.png', 1)
```

```
# Shape returns 3 values: height, width and number of channel in the image
h, w, c = image.shape
image_size = image.size
image_type = image.dtype
```

```
print(f'The image height is {h}, the image width is {w}, the color channel {c}')
print(f'The image size is {image_size} and image type {image_type}')
# Display image
cv2.imshow('Original Image', image)
cv2.waitKey(0)
cv2.destroyAllWindows()
```

```
>> The image height is 284, the image width is 748, the color channel 3
>> The image size is 637296 and image type uint8
```

Basic image processing implementations

Extracting color plans (BGR) in-built function and basic method


- Extracting color plans
- Method one - using *split()* function:
 - Syntax
 - `planB, planG, planR = cv2.split(image)`
- Method two - extracting plan directly:
 - Syntax
 - `planB = image[:, :, 0]`
 - `planG = image[:, :, 1]`
 - `planR = image[:, :, 2]`

Basic image processing implementations

Extracting color plans (BGR) in-built function and plotting them

- Example of separating “*color.png*” using “*colorseparation.py*”
- Method 1:
 - Display windows one by one

```
import cv2
image = cv2.imread("color.png", cv2.IMREAD_COLOR)
B, G, R = cv2.split(image)
# Display original image
cv2.imshow("Original image", image)
cv2.waitKey(0)
cv2.imshow("Blue color plan", B)
cv2.waitKey(0)
cv2.imshow("Green color plan", G)
cv2.waitKey(0)
cv2.imshow("Red color plan", R)
cv2.waitKey(0)
cv2.destroyAllWindows()
```



Basic image processing implementations


Extracting color plans (BGR) basic method and plotting them

- Example of separating “*color.png*” using “*colorseparation2.py*”
- Method 2:
 - Display windows in one go

```
import cv2

# Read image using imread function
image = cv2.imread("color.png", cv2.IMREAD_COLOR)
B = image[:, :, 0]
G = image[:, :, 1]
R = image[:, :, 2]
# Display original image
cv2.imshow("Original image", image)
cv2.imshow("Blue color plan", B)
cv2.imshow("Green color plan", G)
cv2.imshow("Red color plan", R)
cv2.waitKey(0)

cv2.destroyAllWindows()
```



All images are displayed at the same time

Basic image processing implementations

Writing image

- Writing an image using “*imwrite()*” function:
 - Syntax:
 - [status =]cv2.imwrite(‘image_name.ext’, img_var)
 - [status =]: optional, returns *True* if successful, *False* else
 - ‘image_name.ext’: name of the file to save and specify extension
 - img_var: variable to save
- Check if image is saved:
 - Syntax:

```
if status == True:  
    print(f'Written status: {status}')  
else:  
    print(f'Image not saved')
```

Basic image processing implementations

Writing image

- Example of image saving using “*writing_image.py*”

```
import cv2

# Read image using imread function
image = cv2.imread("color.png", cv2.IMREAD_COLOR)

B, G, R = cv2.split(image)

# To get the status of writing the image, save the value into a variable
statusB = cv2.imwrite('colorB.png',B)
if statusB == True:
    print(f'Written B image status: {statusB}')
else:
    print(f'Image B not saved')

>> Written B image stature: True
```

Basic image processing implementations

Plotting live webcam

- Getting camera feed using *VideoCapture()* function:

- Syntax:

```
cap = cv2.VideoCapture(0) # device (0) is usually the main webcam
while True:
    status, frame = cap.read()
    frame = cv2.flip(frame, 1)
    cv2.imshow('Webcam', frame)
    if cv2.waitKey(1) == 27: #esc to stop
        break
cap.release() # release the hardware (webcam)
cv2.destroyAllWindows() # close all windows
```

- status returns *True* if successful, else *False*
 - frame the extracted image from the feed
 - `cv2.flip(image, flag)` flips the image vertically if `flag = 0`, horizontally if `flag = 1` #this is optional
 - `cv2.waitKey(1) == 27`(image, flag) flips 27 corresponds to “esc” key
 - Check code using “*camerafeed.py*”

Basic image processing implementations

Recording video

- Record a webcam feed using *VideoWriter()* function
- Need to run the webcam feed using *VideoCapture()*
 - Syntax:
 - `codec = cv2.VideoWriter_fourcc(*'DIVX')` # Other codecs available
 - `out = cv2.VideoWriter('mywebcamvideo.avi', codec, frame_rate, (width, height))`
 - `out.write(frame)`
 - `out.release()`
 - `codec`: is a 4-byte code used to specify the codec (also referred to as fourcc)
 - `out`: define the video information (name of the file, fourcc codec, number of frame, image size)
 - `out.write(frame)`: save the image “frame” using the parameter of `out` in the specified file
 - `out.release()`: release the video


Basic image processing implementations

Recording video

- Try example using “*record_webcam_video.py*”:

```
import cv2
# Capture video from webcam
cap = cv2.VideoCapture(0)
# frame counter
currentFrame = 0
# Get webcam width
width = cap.get(cv2.CAP_PROP_FRAME_WIDTH)
# Get webcam height
height = cap.get(cv2.CAP_PROP_FRAME_HEIGHT)
# Set codec
codec = cv2.VideoWriter_fourcc(*"DIVX")
out = cv2.VideoWriter('myrecordedvideo.avi', codec, 24.0, (int(width), int(height)))

while cap.isOpened(): # method checking if the capture is properly initialized
    ret_val, frame = cap.read()
    frame = cv2.flip(frame, 1)      # flip the video
    out.write(frame) # save the frame
    cv2.imshow('Live webcam', frame)
    if cv2.waitKey(1) == 27:
        break # esc to quit and stop the video
    currentFrame += 1
cap.release() # release camera
out.release() # release video
cv2.destroyAllWindows()
```



my_webcamv_ideo.avi

Basic image processing implementations

Playing video

- Try example using “*play_video.py*”:

```
import cv2
cap = cv2.VideoCapture('myrecordedvideo.avi')
while cap.isOpened(): # Check that the frame are correctly loaded
    ret, frame = cap.read() # read each frame
    if not ret: # if a frame is defective, print a message
        print(f"problem with frame")
        break
    cv2.imshow('frame', frame)
    if cv2.waitKey(25) == ord('q'): # print a frame every 25 ms or quit with "q"
        break
cap.release()
cv2.destroyAllWindows()
```



my_webcamv_ideo.avi

Basic image processing implementations

Basic image processing outline


- Basic
 - Image reading
 - Image plotting
 - Image properties
 - Image writing
 - Plotting webcam
 - Recording video
 - Playing video
- Histogram
 - What is it?
 - Histogram equalization
 - CLAHE
- Binarization
 - Basic methods
 - Otsu
- Filtering
 - Smoothing filters
 - Average
 - Median
 - Gaussian
 - Sharpening filter
 - Edge Detection
 - Sobel
 - Canny

Basic image processing implementations

Image histogram

- What is an histogram?
 - Distribution of the pixel intensities in an image
 - Statistical information
- Useful transformation:
 - Equalization
 - Exploit the dynamic range of the image
 - Increase the contrast

0	0	0	0	0
0	255	122	122	0
0	255	122	122	0
0	255	122	122	0
0	0	0	0	0



Basic image processing implementations

Plotting histogram using OpenCV of grayscale image

- Extract image histogram using *cv2.calcHist()* function:
 - Syntax:
 - `cv2.calcHist([image], channel, mask, histSize, ranges[, hist[, accumulate]])`
 - [image]: image source
 - channel: index of channel, [0] for grayscale, [0], [1], [2] for blue, green, red channel
 - mask: to work on full image, mask set as “None”
 - histSize: number of bin count (full scale 256)
 - ranges: define range [0, 256]

Basic image processing implementations


Plotting histogram using OpenCV of grayscale image

- Try example using “*histogramOpenCV.py*”:

```
import cv2
from matplotlib import pyplot as plt

# read image
image= cv2.imread('test.png', 0) # 0 to read in grayscale

# Get histogram from 0 to 255
hist = cv2.calcHist([image], [0], None, [256], [0, 256])
cv2.imshow('Loaded image',image)
cv2.waitKey(0)
# show the plotting graph of an image
plt.plot(hist)
plt.title('Loaded image histogram')
plt.show()
cv2.waitKey(0)
```



Basic image processing implementations

Plotting histogram using OpenCV of color image


- Try example using “*histogramcolorimage.py*”:

```
import cv2
from matplotlib import pyplot as plt

image = cv2.imread('imgcolor.png')
color = ('Blue','Green','Red')
for i,col in enumerate(color):
    hist = cv2.calcHist([image],[i],None,[256],[0,256])
    plt.plot(hist,color = col)
    plt.xlim([0,256])
plt.title('Loaded image histogram')
plt.show()
cv2.imshow('Loaded image',image)
cv2.waitKey(0)
```



Original image



Histogram

Basic image processing implementations


Plotting histogram using OpenCV of color image

- Try example using “*histogramcolorimage2.py*”:

```
import cv2
from matplotlib import pyplot as plt
image = cv2.imread('imgcolor.png')
color = ('Blue','Green','Red')
histb = cv2.calcHist([image],[0],None,[256],[0,256]) # extract hist of b
histg = cv2.calcHist([image],[1],None,[256],[0,256]) # extract hist of g
histr = cv2.calcHist([image],[2],None,[256],[0,256]) # extract hist of r
plt.subplot(3,1,1) # use subplot
plt.plot(histb,color = 'Blue')
plt.title('Blue histogram')
plt.subplot(3,1,2)
plt.plot(histg,color = 'Green')
plt.title('Green histogram')
plt.subplot(3,1,3)
plt.plot(histr,color = 'Red')
plt.title('Red histogram')
plt.suptitle('Loaded image histogram')
plt.show()
cv2.imshow('Loaded image',image)
cv2.waitKey(0)
```



Original image



Histogram


Basic image processing implementations

Image histogram equalization

- What is an histogram equalization?
 - Aims to increase global contrast by extending the dynamic range distribution

$$f_{new}[x, y] = (2^D - 1) \cdot \frac{CH(f[x, y])}{wh}$$

- where D: the dynamic range (8 bits), (w, h): image dimension (width and height respectively, CH: the cumulated histogram



Histogram equalization principle*

Basic image processing implementations

Image histogram equalization




- Perform thresholding using *cv2.equalizeHist()* function:
 - Syntax:
 - `eqimage = cv2.equalizeHist(image)`
 - `image`: image source (grayscale)
 - `eqimage`: histogram equalized image

Basic image processing implementations

Image histogram equalization

- Try example using “*histogramequalize.py*”:


```
import cv2
from matplotlib import pyplot as plt
image= cv2.imread('image.png', 0) # 0 to read in grayscale
# Get histogram from 0 to 255
hist = cv2.calcHist([image], [0], None, [256], [0, 256])
histeqimage = cv2.equalizeHist(image) # apply histogram
equalization
histeq = cv2.calcHist([histeqimage], [0], None, [256], [0,
256]) # Get the new histogram
cv2.imshow('Loaded image',image) # Display original image
cv2.imshow('Equalized histogram image',histeqimage) # Display
equalized histogram image
# Plot each histogram
plt.plot(hist)
plt.title('Loaded image histogram')
plt.show()
plt.plot(histeq)
plt.title('Equalized histogram')
plt.show()
cv2.waitKey(0)
```



Basic image processing implementations

Image histogram equalization - CLAHE

- What is CLAHE?
 - Contrast Limited Adaptive Histogram Equalization
 - Parameter 1: contrast limit
 - Parameter 2: tile size
- Equivalent to histogram equalization
- Limited to small region
- Avoid noise amplification



Example of CLAHE moving tile

Basic image processing implementations

Image histogram equalization



- Perform thresholding using “*cv2.createCLAHE()*” function:
 - Syntax:
 - 1: Initiate CLAHE algorithm
 - `clahe = cv2.createCLAHE([clipLimit = 40], [titleGridSize = (8,8)])`
 - 2: Apply method on CLAHE object
 - `claheimage = clahe.apply(image)`
 - `clipLimit`: contrast limit (optional) default value 40.0
 - `titleGridSize`: tiles grid size (optional) default value 8x8
 - `clahe`: CLAHE object to be applied on the image
 - `claheimage`: histogram equalized image using CLAHE

Basic image processing implementations

Image histogram equalization - CLAHE (8x8)

- Try example using “*histogramCLAHE.py*”:

```
import cv2
from matplotlib import pyplot as plt
image= cv2.imread('image.png', 0) # 0 to read in grayscale
# Get histogram from 0 to 255
hist = cv2.calcHist([image], [0], None, [256], [0, 256])
# create a CLAHE object (Arguments are optional).
clahe = cv2.createCLAHE() #clipLimit=40.0, tileGridSize=(8,8)
claheimage = clahe.apply(image)
CLAHEhisteq = cv2.calcHist([claheimage], [0], None, [256],
[0, 256])
cv2.imshow('Loaded image',image) # Plot original image
cv2.imshow('CLAHE image 8x8',claheimage) # Plot CLAHE image
# show the plotting graph of an image
plt.plot(hist)
plt.title('Loaded image histogram')
plt.show()
plt.plot(CLAHEhisteq)
plt.title('CLAHE histogram 8x8')
plt.show()
cv2.waitKey(0) # Close the windows
```






Basic image processing implementations

Image histogram equalization - CLAHE (16x16)





- Try example using “*histogramCLAHE.py*”:

```
import cv2
from matplotlib import pyplot as plt
image= cv2.imread('image.png', 0) # 0 to read in grayscale
# Get histogram from 0 to 255
hist = cv2.calcHist([image], [0], None, [256], [0, 256])
# create a CLAHE object (Arguments are optional).
clahe = cv2.createCLAHE(clipLimit=40.0, tileGridSize=(16,16))
claheimage = clahe.apply(image)
CLAHEhisteq = cv2.calcHist([claheimage], [0], None, [256],
[0, 256])
cv2.imshow('Loaded image',image) # Plot original image
cv2.imshow('CLAHE image 16x16',claheimage) # Plot CLAHE image
# show the plotting graph of an image
plt.plot(hist)
plt.title('Loaded image histogram')
plt.show()
plt.plot(CLAHEhisteq)
plt.title('CLAHE histogram 16x16')
plt.show()
cv2.waitKey(0) # Close the windows
```



Basic image processing implementations

Image - histogram equalization - CLAHE (8x8) - CLAHE (16x16)



Basic image processing implementations

Basic image processing outline

- Basic
 - Image reading
 - Image plotting
 - Image properties
 - Image writing
 - Plotting webcam
 - Recording video
 - Playing video
- Histogram
 - What is it?
 - Histogram equalization
 - CLAHE
- Binarization
 - Basic methods
 - Otsu
- Filtering
 - Smoothing filters
 - Average
 - Median
 - Gaussian
 - Sharpening filter
 - Edge Detection
 - Sobel
 - Canny

Basic image processing implementations

Thresholding

- Binarization of image:
- Most basic method to segment an image
 - Convert grayscale image into black and white image
- Compare pixel intensity value with a set threshold
 - $f_{thresholded}(x, y) = \begin{cases} f_o & \text{for } f(x, y) < V_{thresh} \\ f_{255} & \text{for } f(x, y) > V_{thresh} \end{cases}$
 - where $f_{thresholded}(x, y)$ is the new pixel value after binarization at location x and y
 - f_o is the new pixel value set to **zero** if the original pixel value is lower or equal to V_{thresh}
 - f_{255} is the new pixel value set to **255** if the original pixel value is higher than V_{thresh}
 - V_{thresh} is the threshold value

Basic image processing implementations

Thresholding

- Perform thresholding using *cv2.threshold()* function:
 - Syntax:
 - `ret, threshim = cv2.threshold(image, thresholdValue, maxValue, thresholdingTechnique)`
 - **image:** image source (grayscale)
 - **thresholdValue:** threshold value
 - **maxValue:** Maximum value assigned to a pixel
 - **thresholdTechnique:** type of thresholding applied
 - `cv2.THRESH_BINARY` (basic binarization)
 - `cv2.THRESH_BINARY_INV` (inverted of basic binarization)
 - `cv2.THRESH_TRUNC` (pixel value set to threshold value if higher)
 - `cv2.THRESH_TOZERO` (pixel set to zero for all intensity lower than threshold)
 - `cv2.THRESH_TOZERO_INV` (inverted TOZERO threshold method)
 - **ret:** threshold value
 - **threshim:** binarized image

Basic image processing implementations

Thresholding


- Try example using “*simplebinarization.py*”:
 - Threshold value: 120

```
import cv2

image = cv2.imread('imgcolor.png',0) #Read image in grayscale
cv2.imshow('Loaded image',image) # Plot grayscale image
ret, thresh1 = cv2.threshold(image, 120, 255, cv2.THRESH_BINARY) # Apply binarization with threshold of 120
cv2.imshow('Thresholded image',thresh1) # Plot the binarized image
cv2.waitKey(0) # Close windows
cv2.destroyAllWindows()
```



Grayscale original image



Binarized image with threshold
value of 120

Basic image processing implementations

Thresholding



- Try example using “*simplebinarization.py*”:
 - Threshold value: 150

```
import cv2

image = cv2.imread('imgcolor.png',0) #Read image in grayscale
cv2.imshow('Loaded image',image) # Plot grayscale image
ret, thresh1 = cv2.threshold(image, 150, 255, cv2.THRESH_BINARY) # Apply binarization with threshold of 120
cv2.imshow('Thresholded image',thresh1) # Plot the binarized image
cv2.waitKey(0) # Close windows
cv2.destroyAllWindows()
```



Grayscale original image



Binarized image with threshold
value of 150

Basic image processing implementations

Thresholding


- Try example using “*simplebinarization.py*”:
 - Threshold value: 170

```
import cv2

image = cv2.imread('imgcolor.png',0) #Read image in grayscale
cv2.imshow('Loaded image',image) # Plot grayscale image
ret, thresh1 = cv2.threshold(image, 170, 255, cv2.THRESH_BINARY) # Apply binarization with threshold of 120
cv2.imshow('Thresholded image',thresh1) # Plot the binarized image
cv2.waitKey(0) # Close windows
cv2.destroyAllWindows()
```



Grayscale original image



Binarized image with threshold
value of 170

Basic image processing implementations

Thresholding - Inverted Binarization


- Try example using “*simpleinvertedbinarization.py*”:

```
import cv2

image = cv2.imread('imgcolor.png',0) #Read image in grayscale
cv2.imshow('Loaded image',image) # Plot grayscale image
ret, thresh1 = cv2.threshold(image, 150, 255, cv2.THRESH_BINARY_INV) # Inverted
cv2.imshow('Thresholded image',thresh1) # Plot the binarized image
cv2.waitKey(0) # Close windows
cv2.destroyAllWindows()
```



Grayscale original image



Inverted binarized image with
threshold value of 150

Basic image processing implementations

Thresholding - Inverted Binarization



- Try example using “simpletruncbinarization.py”:

```
import cv2

image = cv2.imread('imgcolor.png',0) #Read image in grayscale
cv2.imshow('Loaded image',image) # Plot grayscale image
ret, thresh1 = cv2.threshold(image, 120, 255, cv2.THRESH_TRUNC) # Inverted
cv2.imshow('Thresholded image',thresh1) # Plot the binarized image
cv2.waitKey(0) # Close windows
cv2.destroyAllWindows()
```



Grayscale original image



Truncated binarized image with threshold value of 150

Basic image processing implementations

Thresholding - Otsu method

- Otsu threshold: Automatic threshold value determination (best used for 2 classes)
- Perform thresholding using *cv2.threshold()* function + *cv2.THRESH_OTSU* flag:
 - Syntax:
 - `retotsu, threshimotsu = cv2.threshold(image, 0, 255,
cv2.THRESH_BINARY+cv2.THRESH_OTSU)`
 - `thresholdTechnique`: type of thresholding applied
 - `cv2.THRESH_BINARY+cv2.THRESH_OTSU`
 - `retotsu`: threshold value determined by Otsu method
 - `threshimotsu`: binarized image using Otsu method

Basic image processing implementations



Thresholding - Otsu method

- Try example using “*otsubinarization.py*”:

```
import cv2
image = cv2.imread('imgcolor.png',0) #Read image in grayscale
cv2.imshow('Loaded image',image) # Plot grayscale image
retotsu, threshotsu = cv2.threshold(image, 0, 255, cv2.THRESH_BINARY+cv2.THRESH_OTSU) # Apply binarization
with Otsu
cv2.imshow(f'Thresholded image: {retotsu}',threshotsu) # Plot the binarized image
print(f'Otsu threshold: {retotsu}')
cv2.waitKey(0) # Close windows
cv2.destroyAllWindows()
```



Grayscale original image



Binarized image using Otsu method

Basic image processing implementations

Thresholding - Otsu method

- Try example using “cameraOtsu.py”:

```
import cv2

cap = cv2.VideoCapture(0)
cv2.namedWindow('Webcam frame', cv2.WINDOW_AUTOSIZE)
while True:
    ret_val, frame = cap.read()
    frame = cv2.flip(frame, 1)
    gray = cv2.cvtColor(frame, cv2.COLOR_BGR2GRAY)
    retotsu, threshotsu = cv2.threshold(gray, 0,
255, cv2.THRESH_BINARY + cv2.THRESH_OTSU) # Apply binarization with
Otsu
    cv2.imshow('Otsu threshold', threshotsu)
    print(f'Otsu threshold: {retotsu}')
    if cv2.waitKey(1) == 27:
        break # esc to quit
cap.release()
cv2.destroyAllWindows()
```



Otsu method applied directly to the camera feed

Basic image processing implementations

Basic image processing outline

- Basic
 - Image reading
 - Image plotting
 - Image properties
 - Image writing
 - Plotting webcam
 - Recording video
 - Playing video
- Histogram
 - What is it?
 - Histogram equalization
 - CLAHE
- Binarization
 - Basic methods
 - Otsu
- Filtering
 - Smoothing filters
 - Average
 - Median
 - Gaussian
 - Sharpening filter
 - Edge Detection
 - Sobel
 - Canny

Basic image processing implementations

Image filtering

- Filters have multiple applications
 - Smoothing (removing noise)
 - Sharpening
 - Edge detection
 - etc.
- Use kernel to determine new pixel value
 - Kernel can have different size and values (based on the application):

1/9	1/9	1/9
1/9	1/9	1/9
1/9	1/9	1/9

3x3 window



1/15	1/15	1/15	1/15	1/15
1/15	1/15	1/15	1/15	1/15
1/15	1/15	1/15	1/15	1/15
1/15	1/15	1/15	1/15	1/15

5x5 window

Basic image processing implementations

Image filtering

- Using kernel on an image
 - Sliding the kernel on every pixel



Basic image processing implementations

Smoothing filter - Average

- Apply average filter using *cv2.blur()* function:
 - Syntax:
 - `blurim = cv2.blur(image, kernelsize)`
 - **image:** input image
 - **kernelsize:** size of the kernel to apply (3,3), (5,5)...
 - **blurim:**blurred image using average technique and defined kernel

1/9		
	1/9	
1/9		1/9
	1/9	

3x3 window

1/15	1/15	1/15	1/15	1/15
1/15	1/15	1/15	1/15	1/15
1/15	1/15	1/15	1/15	1/15
1/15	1/15	1/15	1/15	1/15
1/15	1/15	1/15	1/15	1/15

5x5 window


Basic image processing implementations

Smoothing filter - Average


- Try example using “*blurimage.py*”:

```
import cv2


image = cv2.imread("image.png", cv2.IMREAD_COLOR)
blurim9 = cv2.blur(image, (9,9))
blurim15 = cv2.blur(image, (15,15))
cv2.imshow("Original Image", image)
cv2.imshow("Original Image blurred with 9x9 kernel", blurim9)
cv2.imshow("Original Image blurred with 15x15 kernel", blurim15)
cv2.waitKey(0)
cv2.destroyAllWindows()
```



Original image



9x9 average filter
88




15x15 average filter

Basic image processing implementations

Smoothing filter - Median

- Median filter: Select the median (middle of sorted windows)
- Apply average filter using *cv2.medianBlur()* function:
 - Syntax:
 - `blurim = cv2.medianBlur(image, kernelsize)`
 - **image:** input image
 - **kernelsize:** Must be an odd number (3, 5, etc.)
 - **blurim:** blurred image using median technique and defined kernel




Basic image processing implementations

Smoothing filter - Median


- Try example using “*medianfilter.py*”:

```
import cv2


image = cv2.imread("image.png", cv2.IMREAD_COLOR)
blurim9 = cv2.medianBlur(image, 5)
blurim15 = cv2.blur(image, 9)
cv2.imshow("Original Image", image)
cv2.imshow("Original Image blurred with 9x9 kernel", blurim9)
cv2.imshow("Original Image blurred with 15x15 kernel", blurim15)
cv2.waitKey(0)
cv2.destroyAllWindows()
```



Original image



Size 9 kernel filter
90



Size 15 kernel filter

Basic image processing implementations

Smoothing filter - Gaussian

- Gaussian filter: Select the median (middle of sorted windows)
- Apply average filter using “*cv2.GaussianBlur()*” function:
 - Syntax:
 - `blurim = cv2.GaussianBlur(image, kernelsize[, sigmaX[, dst[, sigmaY[, borderType]]])`
 - `image`: input image
 - `kernelsize`: Gaussian kernel size (width, height) can be different, must be odd
 - `sigmaX` and `SigmaY`: Standard deviation
 - `borderType`: see border types option in OpenCV documentation
 - `blurim`: blurred image using gaussian technique and defined kernel

1/16

1	2	1
2	4	2
1	2	1

3x3 window


Basic image processing implementations

Smoothing filter - Gaussian

- Try example using “*gaussianblur.py*”:

```
import cv2

image = cv2.imread("image.png", cv2.IMREAD_COLOR)
gaussian9 = cv2.GaussianBlur(image, (9,9),cv2.BORDER_DEFAULT)
gaussian15 = cv2.GaussianBlur(image, (15,15),cv2.BORDER_DEFAULT)
cv2.imshow("Original Image", image)
cv2.imshow("Original Image blurred with 9x9 kernel size", gaussian9)
cv2.imshow("Original Image blurred with 15x15 kernel size", gaussian15)
cv2.waitKey(0)
cv2.destroyAllWindows()
```




Original image



Size 9x9 kernel filter

92



Size 15x15 kernel filter

Basic image processing implementations

Sharpening filter

- Image sharpening:
 - Goal is to enhance details in a image
 - Highlight change of intensity
 - Different kernels available
 - Applied through convolution

0	-1	0
-1	5	-1
0	-1	0

Laplacian filter invariant
to 90° rotation

-1	-1	-1
-1	9	-1
-1	-1	-1

Laplacian filter invariant
to 45° rotations

Basic image processing implementations

Sharpening filter

- To apply sharpening filter
- Create a kernel using Numpy:
 - Syntax:
 - `kernel = np.array([[-1, -1, -1], [-1, 9, -1], [-1, -1, -1]])`
 - Apply kernel to image using *filter2D()* function:
 - Syntax:
 - `filteredim = cv2.filter2D(image, ddepth, kernel)`
 - image: original image
 - ddepth: desirable depth of the destination image (-1) output depth same as input depth
 - kernel: kernel to be applied on the image

-1	-1	-1
-1	9	-1
-1	-1	-1

Laplacian filter invariant
to 45° rotations


Basic image processing implementation

Sharpening filter


- Try example using “*sharpenfilter.py*”:

```
import cv2
import numpy as np


image = cv2.imread('image.png')
# Create kernel
kernel45 = np.array([[0, -1, 0], [-1, 5, -1], [0, -1, 0]])
kernel90 = np.array([[[-1, -1, -1], [-1, 9, -1], [-1, -1, -1]]])
# Apply filter
filterimg45 = cv2.filter2D(image, -1, kernel45)
filterimg90 = cv2.filter2D(image, -1, kernel90)
cv2.imshow('Original', image)
cv2.imshow('Sharpened image 45', filterimg45)
cv2.imshow('Sharpened image 90', filterimg90)
cv2.waitKey(0)
cv2.destroyAllWindows()
```



Original image



Sharpen 5



Sharpen 9

Basic image processing implementations

Edge detection

- Edge detection:
 - Boundaries are important features in IP
 - Sudden change of pixel intensity
 - Most common methods:
 - Sobel
 - Canny
 - Laplacian

-1	0	1
-2	0	2
-1	0	1

Sobel vertical direction kernel

1	2	1
0	0	0
-1	-2	-1

Sobel horizontal direction kernel

Basic image processing implementations

Edge detection - Sobel

- Sobel perform edge detection on X and Y direction
- Merge both using bitwise operation
- G_x and G_y the intensity gradient in x and y direction, A and B the horizontal and vertical kernels

$$G_x = A * I$$

$$G_y = B * I$$

where $*$ is the convolution operator and I the image

- The gradient magnitude G is determined using:

$$G = \sqrt{G_x^2 * G_y^2}$$

- The orientation gradient is determined using:

$$\theta = \arctan(G_y / G_x)$$

Basic image processing implementations

Edge detection - Sobel

- Detect edges using sobel method with *cv2.Sobel()* function:
 - Syntax:
 - `sobelim = cv2.Sobel(image, ddepth, dx, dy, ksize)`
 - image: grayscale image
 - ddepth: desirable depth of the destination image (-1) output depth same as input depth, can use `cv2.CV_64F` (corresponding to 64bit floating point)
 - dx: order of the derivative x
 - dy: order of the derivative y
 - ksize: kernel size (1, 3, 5 or 7)
 - sobelim: output image after sobel method

Basic image processing implementations

Edge detection - Sobel

- Try example using “edgesobel.py”:

```
import cv2

image = cv2.imread('cameraman')
grayim = cv2.cvtColor(image, cv2.COLOR_BGR2GRAY)
sobelx = cv2.Sobel(grayim, cv2.CV_64F, 1, 0)
sobely = cv2.Sobel(grayim, cv2.CV_64F, 0, 1)
sobelx = cv2.convertScaleAbs(sobelx)
sobely = cv2.convertScaleAbs(sobely)
sobelxy = cv2.bitwise_or(sobelx, sobely)
sobelxy = cv2.convertScaleAbs(sobelxy)
cv2.imshow('Sobel X', sobelx)
cv2.imshow('Sobel Y', sobely)
cv2.imshow('Sobel X Y using Sobel() function', sobelxy)
cv2.waitKey(0)
cv2.destroyAllWindows()
```



Original image



X sobel, Y Sobel, combined sobel

Basic image processing implementations

Edge detection - Sobel

- Try example using “*sobelcamera.py*”:

```
import cv2
cap = cv2.VideoCapture(0)
cv2.namedWindow('Webcam frame', cv2.WINDOW_AUTOSIZE)
while True:
    ret_val, frame = cap.read()
    frame = cv2.flip(frame, 1)
    grayim = cv2.cvtColor(frame, cv2.COLOR_BGR2GRAY)
    sobelx = cv2.Sobel(grayim, cv2.CV_64F, 1, 0)
    sobely = cv2.Sobel(grayim, cv2.CV_64F, 0, 1)
    sobelx = cv2.convertScaleAbs(sobelx)
    sobely = cv2.convertScaleAbs(sobely)
    sobelxy = cv2.bitwise_or(sobelx, sobely)
    sobelxy = cv2.convertScaleAbs(sobelxy)
    cv2.imshow('Webcam Sobel', sobelxy)
    if cv2.waitKey(1) == 27:
        break # esc to quit
cap.release()
cv2.destroyAllWindows()
```



Sobel applied to camera feed

Basic image processing implementations

Edge detection - Canny

- Canny perform edge detection based on multi-stage process:
 1. Noise reduction
 2. Gradient calculation (Sobel)
 3. Non-maximum suppression
 4. Double threshold
 5. Hysteresis

Basic image processing implementations

Edge detection - Canny

- Detect edges using canny method with *cv2.Canny()* function:
 - Syntax:
 - `cannyim = cv2.Canny(image, lowerT, upperT[, sobelsize[, L2Gradient]])`
 - `image`: grayscale image
 - `lowerT`: Lower threshold value for hysteresis
 - `upperT`: Upper threshold value for hysteresis
 - `sobelsize`: Size of sobel kernel
 - `L2Gradient`: Boolean parameter for more precision
 - `cannyim`: output image after canny method

Basic image processing implementations

Edge detection - Canny


- Try example using “*edgecanny.py*”:

```
import cv2

image = cv2.imread('cameraman.png')
grayim = cv2.cvtColor(image, cv2.COLOR_BGR2GRAY)
blurim = cv2.GaussianBlur(grayim, (3,3), cv2.BORDER_DEFAULT)
lowerT = 75
upperT = 150
cannyim = cv2.Canny(blurim, lowerT, upperT)
cv2.imshow('Canny() function', cannyim)
cv2.waitKey(0)
cv2.destroyAllWindows()
```



Original image




Canny edge

Basic image processing implementations

Edge detection - Canny

- Try example using “*cannycamera.py*”:

```
import cv2
cap = cv2.VideoCapture(0)
cv2.namedWindow('Webcam frame', cv2.WINDOW_AUTOSIZE)
while True:
    ret_val, frame = cap.read()
    frame = cv2.flip(frame, 1)
    grayim = cv2.cvtColor(frame, cv2.COLOR_BGR2GRAY)
    blurim = cv2.GaussianBlur(grayim, (3, 3), cv2.BORDER_DEFAULT)
    lowerT = 50
    upperT = 150
    cannyim = cv2.Canny(blurim, lowerT, upperT)
    cv2.imshow('Webcam Canny', cannyim)
    if cv2.waitKey(1) == 27:
        break # esc to quit
cap.release()
cv2.destroyAllWindows()
```



Canny applied to camera feed

Outlines

- General introduction
 - Bangkok University - BU-CROCCS
 - What is image processing?
 - Applications
- Python + OpenCV
 - Requirements
- Basic image processing implementations
- **Instagram-like filter implementations**
- Conclusions

Instagram-like filter implementations

Why?

- Make your own filters
- Play on different parameters:
 - Saturation
 - Brightness
 - Colour
 - etc.
- Use new OpenCV functions
- Apply directly on video (but easy switch to image)
- Implemented filters:
 - Inverted filter
 - Brightness filter
 - Sepia filter
 - Pencil effect filter

Instagram-like filter implementations

Inverted filter


- Inverted filter...invert the pixel values
 - Subtract 255 and get the absolute value of the pixel
- Done using *cv2.bitwise_not()* function:
 - Syntax
 - `invertedimage = cv2.bitwise_not(image)`
 - `image`: input image
 - `invertedimage`: as the name suggest

Instagram-like filter implementations

Inverted filter

- Try example using “*invertedfiltercamera.py*”:

```
import cv2
cap = cv2.VideoCapture(0)
cv2.namedWindow('Webcam frame', cv2.WINDOW_AUTOSIZE)
while True:
    ret_val, frame = cap.read()
    frame = cv2.flip(frame, 1)
    invertedimage = cv2.bitwise_not(frame)
    cv2.imshow('Inverted image', invertedimage)
    if cv2.waitKey(1) == 27:
        break # esc to quit
cap.release()
cv2.destroyAllWindows()
```



Original image




Image after inverted filter

Instagram-like filter implementations

Brightness filter


- Brightness filter... changes the brightness values
 - Use *cv2.convertScaleAbs()* function and play with the beta value:
 - Syntax
 - `newimage = cv2.convertScaleAbs(image[, alpha= 1[, beta = 0]])`
- image: input image
- alpha: (optional: 1), $0 < \text{alpha} < 1$ lower contrast, $\text{alpha} > 1$ higher contrast
- beta: (optional: 0), $-127 < \text{beta} < 127$ range of brightness

Instagram-like filter implementations


Brightness filter

- Try example using “*brightnessfiltercamera.py*”:


```
import cv2
cap = cv2.VideoCapture(0)
cv2.namedWindow('Webcam frame', cv2.WINDOW_AUTOSIZE)
while True:
    ret_val, frame = cap.read()
    frame = cv2.flip(frame, 1)
    brightimage = cv2.convertScaleAbs(frame, beta = 120)
    cv2.imshow('Inverted image', brightimage)
    if cv2.waitKey(1) == 27:
        break # esc to quit
cap.release()
cv2.destroyAllWindows()
```



Original image



Beta value: 120



Beta value: -20

Instagram-like filter implementations

Sepia filter

- Sepia filter provides a vintage effect
 - Use `cv2.transform()` function and apply a sepia matrix transformation
 - Sepia Matrix
 - $TB = 0.272R + 0.534G + 0.131B$
 - $TG = 0.349R + 0.686G + 0.168B$
 - $TR = 0.393R + 0.769G + 0.189B$
 - Syntax
 - `newimage = cv2.transform(image, matrix)`
 - `image`: input image
 - `matrix`: sepia matrix generated using numpy
 -


Instagram-like filter implementations

Sepia filter


- Try example using “*sepiafiltercamera.py*”:

```
import cv2
import numpy as np

cap = cv2.VideoCapture(0)
cv2.namedWindow('Webcam frame', cv2.WINDOW_AUTOSIZE)
while True:
    ret_val, frame = cap.read()
    frame = cv2.flip(frame, 1)
    frame64 = np.array(frame, dtype=np.float64)
    sepiamatrix = np.matrix([[0.272, 0.534, 0.131],
                           [0.349, 0.686, 0.168],
                           [0.393, 0.769, 0.189]])
    framesepia = cv2.transform(frame64, sepiamatrix)
    framesepia[np.where(framesepia > 255)] = 255
    framesepia = np.array(framesepia, dtype=np.uint8)
    cv2.imshow('Sepia image', framesepia)
    if cv2.waitKey(1) == 27:
        break # esc to quit
cap.release()
cv2.destroyAllWindows()
```



Original image



Applied Sepia filter

Instagram-like filter implementations

Pencil effect filter

- Convert original image into a pencil drawn one
- Existing function in OpenCV to directly obtain both grayscale and color version
- Use *cv2.pencilSketch()* function:
 - Syntax
 - `graypsim, colorpsim = cv2.pencilSketch(image, sigma_s, sigma_r, shade_factor)`
 - `image`: input image
 - `sigma_s`: range between 0 to 200 (control the size of the neighborhood for smoothing)
 - `sigma_r`: range between 0 to 1 (control how dissimilar colors are)
 - `shade_factor`: range between 0 to 0.1 (scaling the intensity, the higher the brighter)
 - `graypsim`: grayscale image of pencil-like non-photorealistic line drawing
 - `colorpsim`: grayscale image of pencil-like non-photorealistic line drawing


Instagram-like filter implementations

Pencil effect filter


- Try example using “*pencilfiltercamera.py*”:

```
import cv2

cap = cv2.VideoCapture(0)
cv2.namedWindow('Webcam frame', cv2.WINDOW_AUTOSIZE)
while True:
    ret_val, frame = cap.read()
    frame = cv2.flip(frame, 1)
    grayspim, colorspim = cv2.pencilSketch(frame, sigma_s=100, sigma_r=0.05, shade_factor=0.05)
    cv2.imshow('Pencil-like image', colorspim)
    if cv2.waitKey(1) == 27:
        break # esc to quit
cap.release()
cv2.destroyAllWindows()
```



Original image



Pencil-like filter

Outlines

- General introduction
 - Bangkok University - BU-CROCCS
 - What is image processing?
 - Applications
- Python + OpenCV
 - Requirements
 - Basic image processing implementations
 - Instagram-like filter implementations
- Conclusions

Conclusion

Quick introduction to basic of image processing

Play and modify the codes as you like

Come to BU for internship !!!

Thank you